


3-4. Using the storage features

List of storage features

Glove box




- 1 Glove box
- 2 Console boxes
- 3 Cup holders
- 4 Bottle holders/door pockets
- 5 Overhead console

3

Interior features

Glove box



- 1 Open (push button)
- 2 Lock with the mechanical key
- 3 Unlock with the mechanical key

n Glove box light

The glove box light turns on when the engine switch is in IG-ON mode.

n Trunk opener main switch

The trunk opener main switch located in the glove box. (→ P. 23)

! CAUTION

n Caution while driving

Keep the glove box closed.


Injuries may result in the event of an accident or sudden braking.

Console boxes



► Front

- 1 Pull up the knob to release the lock.
- 2 Slide armrest.
- 3 Pull up the knob to release the lock.
- 4 Lift the armrest to open.



► Rear (if equipped)

- 1 Press the button to release the lock.
- 2 Lift the armrest to open.

n Console box light (front)

The console box light turn on when the engine switch is in IG-ON mode.

n Using the front console box to store CD cases



Store a CD case with the hinged portion facing either the front or back of the console box.


! CAUTION

n Caution while driving

Keep the console box closed.

Injuries may result in the event of an accident or sudden braking.

Overhead console



The overhead console is useful for temporarily storing sunglasses and similar small items.

⚠ CAUTION

■ Items that should not be left in the overhead console

Do not leave glasses or lighters in the console.


If the interior of the vehicle becomes hot, lighters may explode and glasses may warp or become cracked.

■ Caution while driving

Do not leave the overhead console open while driving.


Items may fall out and cause injury.

Cup holders



► Front (type A)


To open, press down and release the front of the cup holder lid.



► Front (type B)

1 Press the knob to release the lock.

2 Slide armrest.



► Rear

To open, press in and release the rear cup holder on the rear center armrest.

n Using the front cup holder (type B) to store small items



Remove the cup holder insert holding the base part.

! CAUTION


n Items unsuitable for the cup holder

Do not place anything other than cups or aluminum cans in the cup holders. Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury. If possible, cover hot drinks to prevent burns.

n When not in use

Keep the cup holders closed.
Injuries may result in the event of an accident or sudden braking.

Bottle holders/door pockets



The door pocket can be opened and closed.

When installing the bottle, close the cap of the bottle.

CAUTION

Caution while driving

Keep the door pockets closed.

Injuries may result in the event of an accident or sudden braking.